




Dell Inspiron N5110 - WiFi Half Mini PCI card Replacement

Dell Inspiron N5110 - WiFi Half Mini PCI card Replacement

Written By: ZFix



INTRODUCTION

WiFi & Blue-tooth mini PCI card replacement. To change the Wifi card on this model you must to remove the upper case of the laptop. This is not a good engineering designee. We will show you how to do this.

[Please SUBSCRIBE to my channel ツ](#)

[video: <http://youtu.be/Tjo2cGmfRpg>]



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
 - [Metal Spudger](#) (1)
-

Step 1 — WiFi Half Mini PCI card




- Switch off the laptop and remove the battery.
- The keyboard is held by 4x locking clips.
- By using cutter, carefully lift up the one side of the keyboard and start opening the locking clips.

Step 2




- Disconnect the keyboard cable and remove the keyboard.
- Remove the access door screw and the access door
- Remove the screw securing the optical drive, and remove the optical drive

Step 3



- Remove all the screws
- Pry the upper plastic casing off of the laptop

Step 4



- Here is the Wi-Fi card
- Disconnect the antenna cable connectors
- Remove the Wi-Fi card
- .

 [Please SUBSCRIBE to my channel ツ](#)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 04:14:48 AM.

